

# WEC

WHOLESALE EQUIPMENT COMPANY

5355 DISTRIPLEX FARMS DRIVE  
MEMPHIS, TN. 38141

PHONE: 901.366.5767 FAX: 901.366.0093

<http://www.itswec.com>



## T30

Is designed for lockers with handles and a vertical locking bar. Touching the User Button Key to the lock will unlock the 1/2" deadbolt for 10 seconds providing the user ample time before automatically relocking the vertical locking bar. Unlock time can be set to a different value if specified when the order is placed. An optional Time-Set Button Key is also available. T-30 operates on 4-AAA batteries (included). Locking bolt moves horizontally and the lock functions similar to Master Lock Models 1630/31.



## T52

Is designed for box lockers and lockers with a single point latch. Touching the User Button Key to the lock will retract the 1/2" deadlatch for 10 seconds providing the user ample time to open the door. The lock will relock when the locker door is closed. Unlock time can be set to a different value if specified when the order is placed. An optional Time-Set Button Key is also available. T-52 operates on 4-AA batteries (included). Latch moves horizontally and the lock functions similar to Master Lock Models 1652/53 or 1654/55.



## T70

Is designed for all metal locker applications. Touching the User Button Key to the lock will lock and unlock the 1/2" deadbolt. T-70 operates on 4-AAA batteries (included). Locking bolt moves horizontally and the lock functions similar to Master Lock Models 1670/71.

### PROGRAMMING BUTTON KEY

Used for registering User and Management Button Keys to a lock. The keys are registered by touching the Programming Button Key to the lock followed by the User or Management Button Key(s).



### USER BUTTON KEY

Each User Button Key carries a unique identification that eliminates key duplication and unauthorized access. Only one User Button Key can be programmed per lock while multiple locks can be programmed with one key.



### MANAGEMENT BUTTON KEY

Allows access to all locks in the system. Up to 25 Management Button Keys can be programmed per lock.



### TIME-SET BUTTON KEY

T-30 and T-52 are programmed with a 10 second default unlock time. This time can be changed with the use of a Time-Set Button Key.



### POWER JUMPER

When the battery level is low, emits slow battery chirp when used. If the batteries fail, the Power Jumper provides external power to the lock for replacing the batteries located in the rear unit. A valid button key is also required to gain access to the lock.

